
## 87RGB dual mode hot plug instructions

(V1.0 version)



- flicker
- ⑤Turn on BT on a BT-enabled device and search for a connected keyboard. (This product is displayed as "  $c\,m\,a\,n\,y\,$  " on the device  $\,$  side)
- ©After the connection is successful, the P key stops flashing.

Repeat the above steps, you can set up and store three BT devices in the village, switch at any time through  $\mathbb{F}_{\mathbb{R}} + \mathbb{Q}_{\mathfrak{z}}/\mathbb{W}_{\mathfrak{z}}/\mathbb{E}_{\mathfrak{z}}$  when using.

 $\mathbb{F}_{\mathbb{Q}} + \mathbb{Q}_{1} / \mathbb{W}_{2} / \mathbb{E}_{3}$  BT device switching

Supports simultaneous storage of three BT connection information, and can switch devices at will during use. After the switch is successful, the backlit of the keyboard will flash two times.

## Charging instructions ( A BT wireless keyboard only )

In order to protect your normal use, please charge the product before using the product for the first time.

BT version of the keyboard uses 1850 mAh battery, Pay attention to the charger charging 5V 1A, or charge it through the device USB. When charging, the space bar is always on, the red light is always on, it is fully extinguished, and it is full for about 3 hours.

In BT connection mode, no operation for 1 minute, the keyboard backlight automatically turns off and enters standby mode, which can be re-enabled by any